



INSTALLATION INSTRUCTIONS LEDGERS.

Profiled products are typically hollow inside allowing for application over a wood connection strip.

STEP 1.



Once you have finished installing panels, start with Ledgers.

STEP 2.



Mark an straight line ($3/4$ " over the last panel installed). The product cavity should be measured and then the wall marked accordingly.

STEP 3.



Place the wood strip in order to mark the perforations (use $3/32$ " teen reel) nedded to install the anchor(just concrete). Apply minimun 2 perforations, one in each side of the strip, use $3/4$ " screws to fasten the wood strip on the wall.

STEP 4.



The product is mounted onto the connection strip.

STEP 5.



Screws are used to fasten the product to the connection strip.

STEP 6.



FINISHED INSTALLATION.

MAINTENANCE : MOST LOOSE MATERIALS SUCH AS DIRT AND SCUM CAN BE WASHED OFF THE PRODUCT SURFACE WITH PRESSURE APPLIED WATER.