

## INSTALLATION INSTRUCTIONS.

### STEP 1.

---



**A LEVEL LINE SHOULD BE SET PRIOR TO INSTALLING THE PANELS (ALWAYS BEGIN BY THE LOWER PART FROM LEFT TO RIGHT).**

### STEP 2.

---



**MARK THE LOCATION OF THE PANEL PERFORATING WITH A TEEN REEL (3/32") ON THE LAP EDGE. APPLY THE PERFORATIONS EVERY 12".**

### STEP 3.

---



**PERFORATE WITH 1/4" REEL AND PLACE THE ANCHOR OF THE SAME SIZE (ONLY CONCRETE) IN THE MARKED AREA AS SEEN ON STEP 2.**

### STEP 4.

---



**APPLY THE PANEL USING 3/4" SCREWS (A HAMMER DRILL IS USED TO DRILL A HOLE THROUGH THE PRODUCT AND INTO THE MASONERY).**

**STEP 5.**

---



**WHEN A LINE IS FINISHED, THE FOLLOWING ONE BEGINS WITH 8" SEPARATION OF THE BORDER AND THE HOLLOW IS COVERED WITH THE LEFT OVER OF THE SAME LINE. THIS IS DONE EVERY OTHER LINE UNTIL FINISHED.**

**STEP 6.**

---



**INSTALLATION ADVANCE.**

**STEP 7.**

---



**TO FIT A RIGHT ANGLE INSIDE CORNER CUT EACH END AT A 45 DEGREE ANGLE AND SPACE THE JOINT AT APPROXIMATELY A 3/8" GAP. THEN APPLY THE GROUT (OF THE CORRESPONDING COLOR).**





**FINISHED INSTALLATION.**

**SEALANT:** Seal-Krete Original Waterproofer (distributed by Sherwin Williams and others) must be applied, as specified by the manufacturer, to the entire surface area of the products. To maintain the warranty the Seal Krete must be re-applied every five years.

**MAINTENANCE:** MOST LOOSE MATERIALS SUCH AS DIRT AND SCUM CAN BE WASHED OFF THE PRODUCT SURFACE WITH PRESSURE APPLIED WATER.